



ASSOCIATED HOME INSPECTORS



3387 Woodview Drive, SE
Smyrna, GA 30082
770.864.8603 Phone
678.402.6059 Fax

www.associatedhomeinspectors.com



ASSOCIATED HOME INSPECTORS

What we Inspect and What to Expect...



Roof

The inspector shall inspect from ground level or eaves:

- The roof covering
- The gutters
- The downspouts
- The vents, flashings, skylights, chimney and other roof penetrations; and the general structure of the roof from the readily accessible panels, doors or stairs

The inspector is not required to:

- Walk on any pitched roof surface
- Predict the service life expectancy
- Inspect underground downspout diverter drainage pipes
- Remove snow, ice, debris or other conditions that prohibit the observation of the roof surfaces
- Move insulation
- Inspect antennae, lightning arresters, de-icing equipment, or similar attachment
- Walk on any roof areas that appear, in the opinion of the inspector, to be unsafe
- Walk on any roof areas if it might, in the opinion of the inspector, cause damage
- Perform a water test
- Warrant or certify the roof
- Confirm proper fastening



ASSOCIATED HOME INSPECTORS



Exterior

The inspector shall inspect:

- The siding, flashing and trim;
- All exterior doors, decks, stoops, steps, stairs, porches, railings, eaves, soffits and fascias; and report as in need of repair any spacings between intermediate balusters, spindles, or rails for steps, stairways, balconies, and railings that permit the passage of an object greater than 4 inches in diameter
- A representative number of windows;
- The vegetation, surface drainage, and retaining walls when these are likely to adversely affect the structure;
- And describe the exterior wall covering.

The inspector is not required to:

- Inspect or operate screens, storm windows, shutters, awnings, fences, outbuildings, or exterior accent lighting.
- Inspect items, including window and door flashings, which are not visible or readily accessible from the ground.
- Inspect geological, geotechnical, hydrological and/or soil conditions.
- Inspect recreational facilities or playground equipment.
- Inspect seawalls, break-walls and docks.
- Inspect erosion control and earth stabilization measures.
- Inspect for safety-type glass.
- Inspect underground utilities.
- Inspect underground items.
- Inspect wells or springs. Inspect solar, wind, or geothermal systems.
- Inspect swimming pools or spas. Inspect septic systems or cesspools.
- Inspect sprinkler systems.
- Inspect drain fields or drywells.
- Determine the integrity of the thermal window seals or damaged glass.
- Inspect any damaged glass.



ASSOCIATED HOME INSPECTORS



Basement, Foundation, and Crawlspace

The inspector shall inspect:

- The basement
- The foundation
- The crawlspace
- The visible structural components and report on the location of under-floor access openings, and report any present conditions or clear indications of active water penetration observed by the inspector
- For wood in contact or near soil, and report any general indications of foundation movement that are observed by the inspector, such as, but not limited to: sheetrock cracks, brick cracks, out-of-square door frames, or floor slopes and report on any cutting, notching and boring of framing members which may present a structural or safety concern

The inspector is not required to:

- Enter any crawlspaces that are not readily accessible or where entry could cause damage or pose a hazard to the inspector
- Move stored items or debris
- Operate sump pumps with inaccessible floats
- Identify size, spacing, span, location or determine adequacy of foundation bolting, bracing, joists, joist spans or support systems
- Provide any engineering or architectural service
- Report on the adequacy of any structural system or component



ASSOCIATED HOME INSPECTORS



Heating

The inspector shall inspect:

- The heating systems using normal operating
- controls, and describe the energy source and heating method and report as in need of repair heating systems which do not operate and report if the heating systems are deemed inaccessible

The inspector is not required to:

- Inspect or evaluate interiors of flues or chimneys, fire chambers, heat exchangers, combustion air systems, fresh air intakes, humidifiers, dehumidifiers, electronic air filters, geothermal systems or solar heating systems
- Inspect fuel tanks or underground or concealed fuel supply systems. determine the uniformity, temperature, flow, balance, distribution, size, capacity, BTU, or supply adequacy of the heating system
- Light or ignite pilot flames
- Activate heating, heat pump systems or other heating systems when ambient temperatures or other circumstances are not conducive to safe operation or may damage the equipment
- Override electronic thermostats
evaluate fuel quality
- Verify thermostat calibration, heat anticipation, or automatic setbacks, timers, programs or clocks



ASSOCIATED HOME INSPECTORS



Cooling

The inspector shall inspect:

- The central cooling equipment using normal operating controls

The inspector is not required to:

- Determine the uniformity, temperature, flow, balance, distribution, size, capacity, BTU, or supply adequacy of the cooling system
- Inspect window units, through-wall units, or electronic air filters
- Operate equipment or systems if exterior temperature is below 60 degrees fahrenheit, or when other circumstances are not conducive to safe operation, or may damage the equipment. inspect or determine thermostat calibration, cooling anticipation, or automatic setbacks or clocks
- Examine electrical current, coolant fluids or gases, or coolant leakage



ASSOCIATED HOME INSPECTORS



Plumbing

The inspector shall:

- Inspect and determine if the water supply is public or private
- Verify the presence of and identify the location of the main water shut-off valve
- Inspect the water heating equipment, including venting, connections, energy source supply system, and seismic bracing, and verify the presence or absence of temperature-pressure relief valves and/or Watts 210 valves
- Flush toilets
- Water-test sinks, tubs and showers for functional drainage
- Inspect the interior water supply, including all fixtures and faucets
- Inspect the drain, waste and vent systems, including all fixtures
- Describe any visible fuel storage systems
- Inspect the drainage sump pumps and test pumps with accessible floats
- Inspect and describe the water supply, drain, waste and main fuel shut-off valves, as well as the location of the water main and main fuel shut-off valves
- Inspect and report as in need of repair deficiencies in the water supply by viewing the functional flow in two fixtures operated simultaneously
- Inspect and report as in need of repair deficiencies in installation and identification of hot and cold faucets
- Inspect and report as in need of repair mechanical drain-stops that are missing or do not operate if installed in sinks, lavatories and tubs
- Inspect and report as in need of repair commodes that have cracks in the ceramic material, are improperly mounted on the floor, leak, or have tank components which do not operate



ASSOCIATED HOME INSPECTORS



Plumbing, (contd.)

The inspector is not required to:

- Light or ignite pilot flames
- Determine the size, temperature, age, life expectancy or adequacy of the water heater
- Inspect interiors of flues or chimneys, combustion air systems, water softening or filtering systems, well pumps or tanks, safety or shut-off valves, floor drains, lawn sprinkler systems or fire sprinkler systems
- Determine the exact flow rate, volume, pressure, temperature, or adequacy of the water supply
- Determine the water quality or potability or the reliability of the water supply or source
- Open sealed plumbing access panels
- Inspect clothes washing machines or their connections
- Operate any main, branch or fixture valve
- Test shower pans, tub and shower surrounds or enclosures for leakage
- Evaluate the compliance with local or state conservation or energy standards, or the proper design or sizing of any water, waste or venting components, fixtures or piping
- Determine the effectiveness of anti-siphon, back-flow prevention or drain-stop devices
- Determine whether there are sufficient clean-outs for effective cleaning of drains
- Evaluate gas, liquid propane or oil storage tanks
- Inspect any underground or concealed fuel supply systems
- Inspect any private sewage waste disposal system or component thereof
- Inspect water treatment systems or water filters
- Inspect water storage tanks, pressure pumps or bladder tank
- Evaluate wait-time to obtain hot water at fixtures, or perform testing of any kind to water heater elements
- Evaluate or determine the adequacy of combustion air



ASSOCIATED HOME INSPECTORS



Plumbing, (contd.)

The inspector is not required to:

- Test, operate, open or close safety controls, manual stop valves and/or temperature or pressure relief valves
- Examine ancillary systems or components, such as, but not limited to, those relating to solar water heating, hot water circulation
- Determine the existence or condition of polybutylene plumbing



Electrical

The inspector shall inspect:

- The service drop/lateral
- The meter socket enclosures
- The means for disconnecting the service main; and describe the service disconnect amperage rating, if labeled; panelboards and overcurrent devices (breakers and fuses); and report on any unused circuit breaker panel openings that are not filled
- The service grounding and bonding
- A representative number of switches, lighting fixtures, and receptacles, including receptacles observed and deemed to be AFCI-protected during the inspection using an AFCI tester, where possible; and test all Ground Fault Circuit Interrupter (GFCI) receptacles and GFCI circuit breakers observed and deemed to be GFCIs during the inspection using a GFCI tester, where possible; and report the presence of solid conductor aluminum branch circuit wiring, if readily visible; and report on any tested receptacles in which power was not present, polarity is incorrect, is not secured to the wall, the cover is not in place, the ground fault circuit interrupter devices are not properly installed or do not operate properly, evidence of arcing or excessive heat is present, or where the receptacle is not grounded or is not secured to the wall



ASSOCIATED HOME INSPECTORS



Electrical, (cont.)

The inspector shall inspect:

- The service entrance conductors and the condition of the conductor insulation; and report the absence of smoke detectors; and service entrance cables, and report as in need of repair deficiencies in the integrity of the insulation, drip loop, or separation of conductors at weatherheads and clearances from grade or rooftops

The inspector is not required to:

- Insert any tool, probe or device into the main panelboard, sub-panels, distribution panelboards, or electrical fixtures
- Operate electrical systems that are shut down
- Remove panelboard cabinet covers or dead front covers, if they are not readily accessible
- Operate or reset overcurrent protection devices or overload devices
- Operate non-accessible smoke detectors
- Measure or determine the amperage or voltage of the main service equipment, if not visibly labeled
- Inspect the fire or alarm system and components
- Inspect the ancillary wiring or remote control devices
- Activate any electrical systems or branch circuits which are not energized
- Inspect low-voltage systems, electrical de-icing tapes, swimming pool wiring, or any time-controlled devices
- Verify the service ground
- Inspect private or emergency electrical supply sources, including, but not limited to: generators, windmills, photovoltaic solar collectors, or battery or electrical storage facility
- Inspect spark or lightning arrestors



ASSOCIATED HOME INSPECTORS



Electrical, (cont.)

The inspector is not required to:

- Inspect or test de-icing equipment
- Conduct voltage drop calculations
- Determine the accuracy of labeling
- Inspect exterior accent lighting



Fireplace

The inspector shall inspect:

- The fireplace, and open and close the damper door, if readily accessible and operable
- Hearth extensions and other permanently installed components; and report as in need of repair deficiencies in the lintel, hearth and material surrounding the fireplace, including fireplace opening clearance from visible combustible materials

The inspector is not required to:

- Inspect the flue or vent system
- Inspect the interior of chimneys or flues, fire doors or screens, seals or gaskets, or mantels
- Determine the need for a chimney sweep
- Operate gas fireplace inserts
- Light pilot flames
- Determine the appropriateness of any installation
- Inspect automatic fuel-feed devices
- Inspect combustion and/or make-up air devices



ASSOCIATED HOME INSPECTORS



Fireplace, (cont.)

The inspector is not required to:

- Inspect heat distribution assists, whether gravity controlled or fan-assisted
- Ignite or extinguish fires
- Determine adequacy of draft or draft characteristics
- Move fireplace inserts, stoves, or firebox contents
- Perform a smoke test
- Dismantle or remove any component
- Perform a National Fire Prevention Association (NFPA)-style inspection
- Perform a Phase I fireplace and chimney inspection



Attic, Ventilation & Insulation

The inspector shall inspect:

- The insulation in unfinished spaces
- The ventilation of attic spaces
- Mechanical ventilation systems; and report on the general absence or lack of insulation in unfinished spaces

The inspector is not required to:

- Enter the attic or any unfinished spaces that are not readily accessible, or where entry could cause damage or pose a safety hazard to the inspector, in his or her opinion
- To move, touch, or disturb insulation
- To move, touch or disturb vapor retarders
- Break or otherwise damage the surface finish or weather seal on or around access panels and covers
- Identify the composition or exact R-value of insulation material
- Activate thermostatically operated fans



ASSOCIATED HOME INSPECTORS



Attic, Ventilation & Insulation, (cont.)

The inspector is not required to:

- Determine the types of materials used in insulation or wrapping of pipes, ducts, jackets, boilers and wiring
- Determine the adequacy of ventilation.



Doors, Windows & Interior

The inspector shall:

- Open and close a representative number of doors and windows;
- Inspect the walls, ceilings, steps, stairways and railings, and report as in need of repair any spacing between intermediate balusters, spindles or rails for steps, stairways and railings that permit the passage of an object greater than 4 inches in diameter
- Inspect garage doors and garage door openers by operating first by remote (if available), and then by the installed automatic door control; and report as in need of repair any installed electronic sensors that are not operable or not installed at proper heights above the garage door; and report as in need of repair any door locks or side ropes that have not been removed or disabled when garage door opener is in use; and report as in need of repair any windows that are obviously fogged or display other evidence of broken seals



ASSOCIATED HOME INSPECTORS



Doors, Windows & Interior, (cont.)

The inspector is not required to:

- Inspect paint, wallpaper, window treatments or finish treatments
- Inspect central vacuum systems
- Inspect safety glazing
- Inspect security systems or components
- Evaluate the fastening of countertops, cabinets, sink tops or fixtures
- Move furniture, stored items, or any coverings, such as carpets or rugs, in order to inspect the concealed floor structure
- Move drop-ceiling tiles
- Inspect or move any household appliances
- Inspect or operate equipment housed in the garage, except as otherwise noted
- Verify or certify safe operation of any auto-reverse or related safety function of a garage door
- Operate or evaluate any security bar release and opening mechanisms, whether interior or exterior, including their compliance with local, state or federal standards.
- Operate any system, appliance or component that requires the use of special keys, codes, combinations or devices
- Operate or evaluate self-cleaning oven cycles, tilt guards/latches or signal lights.
- Inspect microwave ovens or test leakage from microwave ovens
- Operate or examine any sauna, steam-jenny, kiln, toaster, ice-maker, coffee-maker, can-opener, bread-warmer, blender, instant hot water dispenser, or other small, ancillary devices
- Inspect elevators
- Inspect remote controls
- Inspect appliances
- Inspect items not permanently installed
- Discover firewall compromises



ASSOCIATED HOME INSPECTORS



Doors, Windows & Interior, (cont.)

The inspector is not required to:

- Examine or operate any above-ground, movable, freestanding, or otherwise non-permanently installed pool/spa, recreational equipment or self-contained equipment
- Come into contact with any pool or spa water in order to determine the system structure or components
- Determine the adequacy of spa jet water force or bubble effect
- Determine the structural integrity or leakage of a pool or spa



ASSOCIATED HOME INSPECTORS



Limitations, Exceptions & Exclusions

Limitations:

- An inspection is not technically exhaustive.
- An inspection will not identify concealed or latent defects.
- An inspection will not deal with aesthetic concerns or what could be deemed matters of taste, cosmetic defects, etc.
- An inspection will not determine the suitability of the property for any use.
- An inspection does not determine the market value of the property or its marketability.
- An inspection does not determine the insurability of the property.
- An inspection does not determine the advisability or inadvisability of the purchase of the inspected property.
- An inspection does not determine the life expectancy of the property or any components or systems therein.
- An inspection does not include items not permanently installed.
- These Standards of Practice apply only to homes with four or fewer dwelling units.



ASSOCIATED HOME INSPECTORS



Limitations, Exceptions & Exclusions, (cont.)

Exclusions:

Inspectors are not required to determine:

- Property boundary lines or encroachments. The condition of any component or system that is not readily accessible.
- The service life expectancy of any component or system.
- The size, capacity, BTU, performance, or efficiency of any component or system.
- The cause or reason of any condition.
- The cause for the need of repair or replacement of any system or component. future conditions.
- Compliance with codes or regulations.
- The presence of evidence of rodents, animals or insects.
- The presence of mold, mildew or fungus.
- The presence of air-borne hazards.
- The presence of birds.
- The presence of other flora or fauna.
- The air quality.
- The existence of asbestos.
- The existence of environmental hazards.
- The existence of electro-magnetic fields.
- The presence of hazardous materials including, but not limited to, the presence of lead in paint.
- Any hazardous waste conditions.
- Any manufacturer's recalls or conformance with manufacturer installation, or any information included for consumer protection purposes.
- Operating costs of systems.
- Replacement or repair cost estimates.
- The acoustical properties of any systems.
- Estimates of the cost to operating any given system.



ASSOCIATED HOME INSPECTORS



Limitations, Exceptions & Exclusions, (cont.)

The inspectors are not required to operate

- Any system that is shut down.
- Any system that does not function properly.
or evaluate low-voltage electrical systems such as, but not limited to:
 1. phone lines;
 2. cable lines;
 3. antennae;
 4. lights; or
 5. remote controls.
- Any system that does not turn on with the use of normal operating controls.
- Any shut-off valves or manual stop valves.
- Any electrical disconnect or over current protection devices.
- Any alarm systems.
- Moisture meters, gas detectors or similar equipment.

The inspectors are not required to:

- Move any personal items or other obstructions, such as, but not limited to:
 1. throw rugs;
 2. furniture;
 3. floor or wall coverings;
 4. ceiling tiles;
 5. window coverings;
 6. equipment;
 7. plants;
 8. ice;
 9. debris;
 10. snow;
 11. water;



ASSOCIATED HOME INSPECTORS



Limitations, Exceptions & Exclusions, (cont.)

The inspectors are not required to:

Move any personal items or other obstructions, such as, but not limited to:

- 12. dirt;
- 13. foliage; or
- 14. pets.
- Dismantle, open, or uncover any system or component.
- Enter or access any area which may, in the opinion of the inspector, be unsafe.
- Enter crawlspaces or other areas that are unsafe or not readily accessible.
- Inspect underground items such as, but not limited to, underground storage tanks or other indications of their presence, whether abandoned or actively used.
- Do anything which, in the inspector's opinion, is likely to be unsafe or dangerous to the inspector or others, or damage property, such as, but not limited to: walking on roof surfaces, climbing ladders, entering attic spaces, or negotiating with pets.
- Inspect decorative items.
- Inspect common elements or areas in multi-unit housing.
- Inspect intercoms, speaker systems, radio-controlled security devices, or lawn irrigation systems.
- Offer guarantees or warranties.
- Offer or perform any engineering services.
- Offer or perform any trade or professional service other than home inspection.
- Research the history of the property, report on its potential for alteration, modification, extendibility, or its suitability for a specific or proposed use for occupancy.



ASSOCIATED HOME INSPECTORS



Limitations, Exceptions & Exclusions, (cont.)

The inspectors are not required to:

Move any personal items or other obstructions, such as, but not limited to:

- Determine the age of construction or installation of any system structure or component of a building, or differentiate between original construction and subsequent additions, improvements, renovations or replacements.
- Determine the insurability of a property.
- Perform or offer Phase 1 environmental audits.
- Inspect on any system or component which is not included in these standards